

FLOWLIGHT WAND

Congratulations on getting your flowlight wand! There are several unique features to take note of. Please read this carefully before use:

DURABILITY

Your flowlight wand is made of flowlights that are fused together – do not try to separate the lights. The wand is very durable and can take hits through normal use in dance and levitation play. However it is not designed to handle hard drops or impacts – it is possible to break the wand if it hits a solid object while sweeping through space. It is also possible to hurt another person, so be aware!

INSERTING AND REMOVING BATTERIES

Each flowlight has a clear tab for pulling out the battery. When inserting the battery, always be sure to position the tab across the opening so the battery will be easy to pull out!

The battery compartment is tight to ensure that the battery does not shift around and that the lights do not lose power on impact. You will find that the battery pops out more easily if you work with gravity – face the battery compartment towards the ground when you pop the battery out. If the battery does not come out easily, try tapping the bottom the wand on a hard surface, like a table. It is normal for the battery not to come out all the way, unless you tap the end of the wand.

Be gentle with your battery tab - do not pull too hard on the battery tab or you could tear it off! We do not consider a light with a torn battery tab defective – this is a feature that we added in for convenience. If your battery tab gets pulled off accidentally, you can thread some thread through one of the holes in the board to make your own pull-tab to help pop the battery out.

If for some reason the tab is not accessible, you can pop the battery out using a key or similar object on the end of the battery (not the side!), then tap the end of the wand to get it out all the way.

Tip: Flowlights are optimized for rechargeable NiMH and good alkalines – they under-perform with cheap alkalines. The lights are bright and draw a lot of power, so cheapo batteries or rechargeable NiCD and alkalines don't last as long, can't keep up and make the light turn off easily. The difference can be your lights lasting 10 minutes or 7 hours. Please use rechargeable NiMHs or great quality alkalines for the best experience with your lights.

FLOWLIGHT WAND STRING AND FINGER LOOP

The string is a very durable braided nylon that we have not been able to break during normal use. You can really yank on it, but it is possible it could break at some point or get hopelessly tangled, so we've included some extra, just in case. You can also purchase extra string on our website if you want to make a wand with a longer string.

There's a strong nylon finger loop with a swivel to prevent the string from getting to twisted during play. We designed the finger-loop to be one-size-fits-all, snug, comfortable and easy to use. It should naturally tighten around your finger and may restrict bloodflow overtime, so give your finger a rest once in awhile.

STORING YOUR WAND IN THE TUBE-CASE and OUT OF THE SUN

The epoxy connection between the lights is very strong, but can warp if stored improperly. We recommend always storing your wand in its tube-case when not using it. Also keep your wand out of the sun as much as possible – all plastics degrade in UV and leaving your wand out in the sun will weaken it/shorten its lifetime.

When inserting your wand into the case, the string must be straight (do not twist around the wand) and the finger-loop and swivel should rest on the side of the top-most flowlight to fit in the case. The case is very strong and also makes a great baton with the wand inside! Your wand is tough and dropping it while in the case should not hurt it - have fun!

The tube-case is compatible with the flowtoys modular system, but to make the case as compact as possible for transport, the flower caps do not have bumpers inside and will not connect to flowlights the same way as other flower caps do.

WARRANTY AND REPLACEMENT POLICY

Your flowlight wand has a lifetime warranty against manufacturing defects. While the wand is durable, we also understand that accidents happen or that people can play hard. If you happen to break your flowlight wand at any time, it falls under the same replacement policy as other flowtoys. Contact us at info@flowtoys.com for information on how to send back the parts with the carrying case, and you will receive half credit on what you paid for the wand towards a replacement.

Thanks for spreading the light!